

VAPORISED HYDROGENPEROXIDE ROOM/CABINET STERILISATION SYSTEM VHP







### **Applications:**

- High Patogene Virus and Microbiology Laboratories
- Hospitals and Healthcare related decontamination,
- Temperature sensitive equipment sterilisation
- Tacticle Vehicle sterilisation,
- Aircraft sterilisation,
- Biotechnological and Pharmaceutical Factories,
- Biosafety cabinets, isolators,
- BSL-3/4 Laboratories and Animal Laboratories.







Our body fights with the foreign microoganisms producing H2O2 in the our cell. If our immune system sense a bacterial attack Peroxizome enzimes produced for producing H2O2, on the contrary to balance and to control H2O2 level peroxiredoxin enzimes produced to convert H2O2 to H2O and O2. Some Scientists thinks that if this balance break down it causes cancer and diabet.



#### HYDROGENPEROXIDE COMBINES FROM TWO HYROGEN AND TWO OXIGEN ATOM AND KILLS:



Bacterial endospores



Small nonenveloped viruses



Mycobacteria



Gram-negative bacteria




#### HYDROGENPEROXIDE COMBINES FROM TWO HYDROGEN AND TWO OXIGEN ATOM AND KILLS:




Fungi



Gram-positive Bacteria



Large nonenveloped viruses



**Enveloped viruses** 

Page 4/ 15




Hydrogen peroxide vapour is well established as a bio-decontamination agent due to its "residue free" nature (the only residues are oxygen and water) and low temperature, vapour-phase application.

HPV has been tested against many organisms and classes of organisms. However, because a great number of "common" micro-organisms exist, efficacy testing remains an ongoing process.

HPV has been shown to kill a wide range of micro-organisms including bacteria, viruses and fungi. The efficacy of HPV has been repeatedly demonstrated against bacterial endospores, which are typically the most resistant organism to any kind of bio-deactivation stress so as such are positioned at the top of the Spaulding classification.



# Hydrogen Peroxide Vapor





## Why H<sub>2</sub>O<sub>2</sub> Vapor?

Hydrogen

Chlorine Dioxide

**Formaldehyde** 

<u>Peroxide</u>

Skin/eye irritant Severe irritant

Human Carcinogen

PEL 1.0 ppm

PEL 0.1 ppm

PEL 0.75 ppm STEL 2 ppm

IDLH 75 ppm

STEL 0.3 ppm IDLH 5.0 ppm

IDLH 10 ppm

PEL - Personal Exposure Limit (8 hours)

STEL - Short-term Exposure Limit (15 min.)

IDLH – Immediately Dangerous to Life or Health




#### **Limitations:**

- Temperature: Water vapour and H2O2 shares the same partial vapour pressure. So at the low temperature we can't reach the necessary ppm level. For example not used for coldrooms.
- Liquids
- Open areas: To reach the necessary ppm we need close areas.



## **Typical process cyle**





#### **Process:**

- Prepare the room
  - Remove or reduce clutter . Spores are harder to kill on the porous absorbent ma terials like paper
  - Clean surfaces especially spills occur
  - Shut of air supply and exhaust
  - Recirculate biological safety cabinets
  - Place biological and chemical indicators
    - Geobacillius steraoiththermophilus
    - 10<sup>6</sup> spores per sample are typical for bio-safety applications
    - Minimum 10-12 sample for smaller applications 1 sample for 10 sqm for larger applications
    - Chemical indicators
  - Place fan for turbulance
  - Seal doors and openings with tape
  - Place warning signs





#### **Process:**

- High humidity limits the H2O2 given to the room. So first step is dehumidifying the room. (The unit does it)
- After dehumidfiying supplying H2O2 vapour starts
- According to the room structure required ppm level maintain the necessary time. Sterilisation obtained.
- After sterilisation decomposition (deactivation) of the H2O2 starts. With a special catalisor H2O2 converted to H2O and O2.
- Decomposition of the H2O2 is very fast in the beginning of the periotd and slow down hiperbolicly.
  So; in most cases exhaust sytem used to reach the safety zone.
- To enter the room H2O2 should be <= 1 ppm.



















TECHNÍCAL DATA OF HTL-PEROXMIN	
Properties	Value/Explanation
Dimension w x d x h (mm)	730 x 920 x 790
Weight	87 kg
Size for shipment	1 std. Euro-pallet
Electrical connection	230 V/50 Hz , 16 A
Power consumption max. Kw	2.8 kw
Quick connectors for the gas circuit	Kamlock coupling 1" male and female
Quick connectors side	On the rear side, other connectors on request
Control system	PLC+Touchmatic multicolour panel
Check balance (Note This is 300 Euro, w/o verification 200 Euro)	KERN FOB5K2LM (6000 g /2g), with verification
Output	3" thermal printer
Sterile filter	Vokes Hepatex 13 ( Optionally H14)
Blower	EBMPAPST 60 m3/h
Valves	Electrically driven
Humidity sensor	Quick responding Driesen&Kern SK470
Disinfection agent	Hydrogen peroxide 35 (395 g/l) standard grade
Dasing	PLC controlled peristaltic pump
H2O2 holding container	Standard chemical can 1-5 liters (Suction tubing and aeration opening recomended; will be supplied together with a 2 liters can)

#### **OPTIONS**

in-line measuremet of H2O2 concentration by a Dräger Polytron 7000, integrated into the gas return piping.

OEM-version for the integration into isolators, locks, etc. on specific request.